



NOTES
 * CALIBRATION RESISTOR FOR COARSE CENTERING.
 @ R208A PARALLELS R208.
 CAPACITANCE IN MICROFARADS UNLESS OTHERWISE NOTED.
 ▲ R131 TO R137 = 68 Ω.

FOR USE WITH SERIAL NO'S
 4000 & ABOVE